


QUICK START


Please refer to the instruction booklet for more detailed information



FILLING




Press the red tab under the tank and slide the tank out. Fill it with water up to the **MAX** mark.




Slide the tank back in until it clicks. When the tank is correctly fitted, the red tab will show.


IRONING WITH STEAM




Turn the temperature control to the desired heat setting. For steam ironing, this **MUST** be either **HIGH** (●●●) or **MAX** otherwise water will drip from the soleplate during ironing.



Press the steam control button to select the desired amount of steam (**LOW**, **MED** or **HIGH**). Wait until the **HEAT** indicator light stops flashing and stays lit. Your steam generator is now ready to produce steam



Wait until the temperature indicator light stops flashing and stays lit. Your iron is now at the correct temperature to use.



Press the steam trigger when steam is needed.

NEED MORE HELP?



CUSTOMER SERVICES
0161 621 6900




info@pulse-uk.co.uk

QUICK START


Please refer to the instruction booklet for more detailed information




IRONING WITHOUT STEAM




Turn the temperature control to the desired heat setting.



You don't need to adjust any of the steam controls when ironing without steam.



Wait until the temperature indicator light stops flashing and stays lit. Your iron is now at the correct temperature to use.



Iron **WITHOUT** pressing the steam trigger.

TROUBLESHOOTING

No steam	<p>Check that there is water in the tank</p> <p>Check that the water tank is fitted correctly (e.g. is the red tab visible?)</p> <p>Check that the HEAT indicator light has stopped flashing and is ON</p> <p>Check that the iron is up to temperature (the temperature indicator light is ON)</p>
Water drips from the soleplate during steam ironing	<p>Check that the temperature control is between HIGH (●●●) and MAX</p> <p>Check that the iron is up to temperature (the temperature indicator light is ON)</p>
Water drips from the soleplate during dry (no steam) ironing	<p>Don't press the steam trigger during ironing</p>

NEED MORE HELP?



CUSTOMER SERVICES
0161 621 6900



info@pulse-uk.co.uk