

# Breville®

Turn **on** your creativity™



**halo**  
health fryer

## **IMPORTANT SAFETY INSTRUCTIONS.**

### **READ CAREFULLY AND KEEP FOR FUTURE REFERENCE**

**This appliance shall not be used by children from 0 year to 8 years. This appliance can be used by children aged from 8 years and above if they are continuously supervised. This appliance can be used by people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.**

**Keep the product and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance must not be done by children.**

**This product must be positioned on a stable surface with the handles positioned to avoid the spillage of hot liquids.**

**Surfaces of the product are liable to get hot during use.**


**Never operate the product by means of an external timer or separate remote-control system.**





**If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

- 
- ⚠ Never use this appliance for anything other than its intended use. This appliance is for household use only. Do not use this appliance outdoors.
  - ⚠ Always ensure that hands are dry before handling the plug or switching on the appliance.
  - ⚠ Always use the appliance on a stable, secure, dry and level surface.
  - ⚠ Ensure the appliance is switched off and unplugged from the supply socket if it is left unattended, when it is not in use or before cleaning. Never leave the appliance unattended when it is in use.
  - ⚠ Always allow the appliance to fully cool down before cleaning or storing.
  - ⚠ Do not use the appliance if it has been dropped, if there are any visible signs of damage or if it is leaking.
  - ⚠ Never immerse any part of the appliance or power cord and plug in water or any other liquid.
  - ⚠ Never let the power cord hang over the edge of a work top, touch hot surfaces or become knotted, trapped or pinched.
  - ⚠ Do not touch the external surfaces of the appliance during use as they may become very hot.
  - ⚠ Only use spares or accessories that are recommended by the manufacturer.

# parts

---

1. Lid
2. Halogen heater and fan assembly
3. Lid release button
4. Display
5. Timer setting button
6. On/off button
7. Paddle
8. Oil measure  (approximately equal to 15ml)
9. Dual height wire rack
10. Removable non-stick bowl
11. Detachable bowl handle
12. Bowl roller assembly



Due to our policy of continuous improvement, the actual product may differ slightly from the one illustrated in these instructions.

# before first use


---

**⚠ Never immerse any part of the fryer body, power cord or plug in water or any other liquid. Before assembling or disassembling your fryer, ensure it is unplugged and all parts are cool.**

Unpack the appliance and remove all packaging, promotional materials and stickers. Remove all printed documents. Wash the removable bowl, paddle, measuring spoon, wire rack and bowl handle in hot soapy water. Rinse then dry all of the parts. Wipe the body and lid with a damp cloth only—see page 16 for cleaning instructions.

## Assembling the paddle


1. Push the handle firmly into the hole in the paddle until it clicks. Once assembled, do not try to remove the handle from the paddle otherwise it may be damaged.



## Fitting the bowl roller assembly

The bowl roller assembly must be fitted the correct way up as shown in figure 1 below. Two of the wheel axles are stamped with the word 'UP'. These must face upwards when the roller is correctly fitted. If, during use, the bowl makes excessive noise or fails to rotate properly, make sure that the bowl roller assembly is fitted the right way up.


1. Place the bowl roller assembly centrally into the bottom of your Halo Health Fryer.
2. Place the bowl into the body of your fryer as shown in figure 2 below.



**▲ During cooking the removable bowl rotates so only use the handle to remove the bowl after cooking has finished. Remember the bowl will be very hot! Don't set the bowl down on a surface that may be damaged by heat.**

After cooking, you can use the detachable bowl handle to remove the bowl and its contents safely.

1. Place the bowl handle over the lip of the removable bowl
2. Lower the handle onto the bowl
3. Slide the lever forwards. The handle will grip the bowl. Let the lever return to its rest position.
4. Lift the bowl out of the fryer body.
5. To release the bowl, press the button on the handle.
6. Lift the handle off the rim of the bowl.



# cooking chips

---

**▲ Always use your fryer on a stable, secure, dry and level surface.**

**Allow adequate space above and on all sides for air circulation.**

**Do not allow the appliance to touch any flammable material during use (such as curtains or wall coverings).**

**Care is required when using the appliance on surfaces that may be damaged by heat. The use of an insulated pad is recommended.**

Your Halo fryer can be used to cook fresh or frozen chips, however, for the healthiest option, we suggest you try our perfect homemade chips on page 17.

Cooking chips uses the paddle to ensure even cooking. Foods such as mushrooms, diced potatoes, etc. can also be cooked using the paddle.

1. Press the lid release button and open the lid.
2. Fit the removable bowl then fit the paddle onto the spindle in the bowl.
3. Add the chips to the bowl. Distribute the chips evenly over the bottom of the bowl and don't exceed the MAX indicator line on the bowl.
4. Add the recommended quantity of oil to the chips using the cooking oil measure. Spread the oil evenly over the chips. Please refer to our cooking popular, convenience and frozen foods guide on page 14-15.
5. Close the lid and plug your fryer into a suitable mains supply and switch the socket on. Your fryer will beep, the display will light up blue and after a second or two will show *00*.

Use the TIME button to enter the desired cooking time in minutes. If you keep your finger on the TIME button, the time will increase quickly. When you are near the desired time, make single presses of the button.

If you make a mistake press and hold the on/off button until your fryer beeps and the display once again shows *00*. Re-enter the time as described above.





6. Press the on/off button and the display will turn orange, the halogen heater will illuminate and the fan will start. The timer will start to count down in minutes until 1 minute remains when it will count down in seconds.
7. When the cooking time has ended, your fryer will beep and the halogen heater will turn off. The fan will continue running until you open the lid.

## Notes

During cooking, you may open the lid at any time by pressing the lid release button. Doing this will switch off the halogen heater and the fan but the timer will continue to count down. Closing the lid will restart cooking. If you have had the lid open for some time, you may need compensate with additional cooking time after the original time has elapsed.

During cooking, the halogen heater will switch on and off from time to time. This is normal and allows your Halo Health Fryer to maintain an even cooking temperature.





# other cooking methods

---

Your Halo Health Fryer comes complete with a dual height rack that can be used for a variety of foods e.g. sausage, chicken, chips, fish, etc. Foods can also be cooked directly in the removable bowl with or without the paddle. Use whichever method gives you the best results.

1. The rack can be used either way up to bring food closer to, or further from the halogen heater.
2. Press the release button and open the lid. Place the rack into the removable bowl whichever way up you require.
3. Place the food on the rack. The rack and food will rotate during cooking so make sure that the food will not touch any part of the halogen heater/fan assembly or other part of the lid when it is closed.
4. If required, add oil evenly over the food.
5. Close the lid and plug your fryer into a suitable mains supply and switch the socket on. Your fryer will beep, the display will light up blue and after a second or two will show *00*.

Use the TIME button to enter the desired cooking time in minutes. If you keep your finger on the TIME button, the time will increase quickly. When you are near the desired time, make single presses of the button.

If you make a mistake press and hold the on/off button until your fryer beeps and the display once again shows *00*. Re-enter the time as described above.


6. Press the on/off button and the display will turn orange, the halogen heater will illuminate and the fan will start. The timer will start to count down in minutes until 1 minute remains when it will count down in seconds.
7. When the cooking time has ended, your fryer will beep and the halogen heater will turn off. The fan will continue running until you open the lid.

## Notes


During cooking, you may open the lid at any time by pressing the lid release button. Doing this will switch off the halogen heater and the fan but the timer will continue to count down. Closing the lid will restart cooking. If you have had the lid open for some time, you may need to readjust the cooking time.

During cooking, the halogen heater will switch on and off from time to time. This is normal and allows your Halo Health Fryer to maintain an even cooking temperature.

1




LOW POSITION




HIGH POSITION

2




3




4



5



6



# guide to oils and fats

---

Using your Halo Health Fryer to cook food will help you to reduce the amount of oil needed in some recipes, which may benefit your diet.

The table below lists some of the more widely available, popular oils. All of them can be used in your Halo Health Fryer. However, for best results, we recommend Vegetable or Rapeseed oil.

<b>Oil Type</b>	<b>Use</b>
Vegetable oil	Shallow, deep and stir frying.
Rapeseed oil (often called vegetable oil)	Shallow, deep and stir frying.
Corn oil	Shallow, deep and stir frying.
Sunflower oil	Shallow, deep and stir frying.
Olive oil	Shallow and stir frying. Marinades, dressings, drizzling.
Sesame oil	Shallow, deep and stir frying. Marinades, drizzling.
Peanut oil (often called ground nut oil)	Shallow and stir frying. Dressings. Adds a nutty flavour.
Grape Seed oil	Shallow, deep and stir frying.

- You can also use low calorie cooking spray in your Halo Health Fryer
- Always ensure that the ingredients are evenly coated with oil.

There is nothing quite like a plate of homemade chips—especially with your Halo Health Fryer doing all the hard work for you.

Did you know there are hundreds of varieties of potatoes grown around the world with about 80 different varieties grown commercially in the UK. Potatoes are usually divided into two categories:

**Floury potatoes** – These are generally lighter in colour, with a drier feel, perfect for homemade chips and jacket potatoes. Well known varieties are King Edward, Maris Piper and Rooster.

**Waxy potatoes** – These are moist, firm and translucent and hold their shape well—great in salads. Examples of these include Charlotte and Jersey Royals

When choosing potatoes for our recipes, it's worth buying the right type to achieve the best results. Many potatoes can be used for a variety of purposes. For example, the King Edward potato can be used for both homemade chips and our Dauphinoise recipe.

Usage	Variety
Homemade chips, cajun-style potatoes, roast potatoes	Maris Piper, King Edward, Sante, Rooster, Romano
Dauphinoise	Charlotte, Desiree
Jacket potatoes	Maris Piper, King Edward

# cooking popular, convenience and frozen foods

Food	Approx. Time (minutes)	Instructions
Jacket potatoes	50-55	Prick and space evenly apart
1kg of fresh chips	40-55	Wash and dry
800g of fresh chips	30-35	Wash and dry
500g of fresh chips	30-35	Wash and dry
1kg of frozen chips	35-40	Shake off excess ice
800g of frozen chips	25-30	Shake off excess ice
500g of frozen chips	25-30	Shake off excess ice
Chicken legs/drumsticks	30-35	Turn occasionally for even browning
Stir fried vegetables	8-10	Cut into evenly sized pieces
Sausages	10-12	Turn once halfway through cooking
Salmon fillet	8-10	Lightly oil the grill rack
Frozen chicken nuggets	18-20	Turn occasionally
Frozen breaded scampi	12-15	Turn occasionally
Frozen fish fingers	10-12	Turn once halfway through cooking
Lamb cutlets/chops/leg steaks	15-25	Turn once halfway through cooking
Turkey/chicken breast	15	Turn once halfway through cooking
Pork chops	12-15	Turn once halfway through cooking
Uncooked prawns	6-8	Wash, peel and de-vein
Cooked prawns	3-5	
Burgers	16-19	Turn once halfway through cooking
Steak, beef sirloin/rump	5-6 (rare) 8-10 (medium) 12-14 (well done)	Turn once halfway through cooking
Cheese on toast	7	Cook toast first then add cheese
Grilled bacon	8	Turn over halfway through cooking to brown
Individual frozen chicken pie	15-20	

	<b>Accessory Required</b>	<b>Oil</b>
	Bowl only	Lightly oil the skins for crispy results
	Paddle	1 measure
	Paddle	1 measure
	Paddle	½ measure
	Paddle	None
	Paddle	None
	Paddle	None
	Grill rack in low position	None
	Paddle	1 measure
	Grill rack in low position	None
	Grill rack in low position	Oil the grill rack only
	Bowl only	None
	Bowl only	None
	Grill rack in low position	None
	Grill rack in low position	None
	Grill rack in low position	Lightly oil the grill rack
	Grill rack in low position	None
	Bowl only	None
	Bowl only	None
	Grill rack in low position	Lightly oil the grill rack
	Grill rack in low position	None
	Grill rack in high position	None
	Grill rack in high position	None
	Bowl only	None

# care and cleaning

---

**⚠ Always unplug your Halo Health Fryer and allow it to cool completely before cleaning it.**

**NEVER immerse the body, power cord or plug in water or any other liquid.**

**Never use harsh abrasive cleaners or cleaning materials.**


- Inside the lid, carefully wipe any oil spatter from the halogen heater/fan assembly cover with kitchen paper. Wipe over the outer body and lid with a clean, slightly damp cloth and dry.
- Wash the rack, paddle, cooking oil measure, removable bowl and bowl handle by hand in warm soapy water using a cloth, sponge or brush. Dry completely before use or storage.
- The rack, paddle, cooking oil measure and removable bowl may be washed in a dishwasher.




# recipes - side dishes and snacks

---


For a guide to cooking popular, convenience and frozen foods, see page 14-15.

When necessary, this symbol  will show you how much oil to add using the supplied oil measure.


## Perfect Homemade Chips (Serves 4)

- 800g of potatoes (Floury potatoes such as Maris Piper or King Edward are the best)
  - 1  of vegetable oil
  - Salt to serve
1. Fit the paddle into your Halo Health Fryer.
  2. Peel the potatoes and chip them into approximately 11-13 mm wide chips with a sharp knife.
  3. Rinse them twice to remove the starch and completely cover them with water until you are ready to cook them.
  4. When you are ready to cook them, drain the chips and pat them dry to remove the excess moisture.
  5. Place them in the bowl and drizzle one tablespoon of oil over them.
  6. Set the timer for about 30 to 35 minutes and cook them until they are golden and crisp. Sprinkle with salt and serve hot.

## Cajun-Style Potatoes (Serves 4)

- 800g of small potatoes, skins left on but well washed
  - 3  of olive oil
  - 1 clove garlic, crushed
  - 1 tablespoon of Cajun spices
  - 2 tablespoons of plain flour
  - Salt and freshly ground black pepper
1. Fit the paddle into your Halo Health Fryer.
  2. Cut the potatoes into chunky-style chips 15-20mm wide with a sharp knife. Rinse them twice to remove the starch then completely cover with water until you are ready to cook them.
  3. When you are ready to cook them, drain and pat the potatoes dry with kitchen paper.
  4. Coat them with two tablespoons of the olive oil and the crushed garlic.
  5. Mix together the flour and Cajun spices and toss the potatoes in this mixture so they are well coated.
  6. Place the potatoes in the bowl and pour the remaining olive oil over them.
  7. Cook for 35 to 40 minutes until they are golden and crisp.

## Perfect Roasted New Potatoes (Serves 4)


- 800g new potatoes, halved but with the skins still on
  - 2  of light olive oil
  - 1 teaspoon of mixed herbs
  - Salt and Pepper
  - 2 garlic cloves, unpeeled
1. Remove the paddle from your Halo Health Fryer.
  2. Parboil the potatoes for approximately 15mins or until they are softened on the hob, then pat them dry.
  3. Place the new potatoes into a large mixing bowl and add 1 tablespoon of the oil, mixed herbs and season with a generous amount of salt and pepper.
  4. Mix the contents of the bowl using your fingers or a spoon until the potatoes are well coated. Be careful to not break the potatoes up too much.
  5. Place the potatoes in the bowl. Gently crush the unpeeled garlic and add the pieces evenly to the potatoes.
  6. Drizzle with the remaining oil and cook for 15-20mins.

## Cheesy Nacho's with Spicy Tomato Salsa (V)

- 1 large bag of plain nachos
  - 100g of cheddar cheese
  - ½ green chill, deseeded and sliced
  - Sour cream, salsa and Guacamole to serve
1. Remove the paddle from your Halo Health Fryer and lightly oil the removable bowl.
  2. Evenly scatter the nachos over the bottom of the bowl.
  3. Sprinkle the nachos with cheese and the green chilli and then cook them for approximately 2-3 minutes until the cheese has melted.
  4. Serve the nachos topped with the spicy tomato salsa, sour cream and guacamole.

---


## Stuffed Jacket Potatoes with Cheese and Bacon (Serves 4)

- 8 small or 4 medium jacket potatoes, cleaned with the skins still on
  - 200g of bacon rashers, trimmed and cut into strips
  - 100g Emmental cheese, grated
  - 2 shallots, diced
  - 75ml milk
  - 25g butter
  - Salt and Pepper
  - Worcestershire Sauce
  - 2 tablespoons of flat leaf parsley
  - 1  of oil
1. Remove the paddle from your Halo Health Fryer.
  2. Prick the potatoes all over and add to the removable bowl along with the oil.
  3. Cook for 55-60 minutes or until they are soft when they are squeezed. Once they are finished remove the potatoes from your fryer. Carefully slice them in half lengthways. Wear oven gloves and be careful not to tear the skin. Set to one side to cool then fit the paddle into your Halo Health Fryer.
  4. Add the bacon, shallots and a dash of oil and cook for 10 mins or until cooked and golden in colour.
  5. Meanwhile, wearing oven gloves remove the potato from the skins using a tablespoon and add to a large mixing bowl. Set the potato skins to one side.
  6. Add the milk, butter and  $\frac{3}{4}$  of the cheese to the bowl and season to taste. Use a fork to mash it together until it is smooth. Then add the bacon and onions and carefully stir in.
  7. Spoon the mixture back into the potato skins and sprinkle with the remaining cheese and a dash of Worcestershire sauce.
  8. Remove the paddle from your Halo Health Fryer then gently place the potatoes back into the bowl and cook for a further 10 minutes until the cheese turns crispy and golden.

## Gratin Dauphinoise (Serves 4)


- 500g waxy potatoes (e.g. Charlotte, Desirée or King Edward)
  - 1 garlic clove, crushed
  - 150ml full fat milk combined with 130ml double cream
  - Pinch of freshly grated nutmeg
  - 25g butter
  - Salt and freshly ground black pepper
  - 50g freshly grated parmesan cheese
1. Remove the paddle from your Halo Health Fryer.
  2. Peel the potatoes and slice them very thinly. Place them in a bowl of water for a few seconds to remove some of the starch then pat them dry on kitchen paper.
  3. Layer half of the potatoes along the bottom of the bowl slightly overlapping each potato with the next. Pour half of the milk and cream mixture onto the potatoes. Season this layer with salt and pepper and a sprinkle of the garlic.
  4. Layer the remaining potatoes on top of the last layer then pour the remaining milk and cream mixture over the potatoes. Season with salt and pepper, sprinkle with the remaining garlic and the parmesan cheese.
  5. Cut the butter into cubes and dot over the potatoes and add a sprinkle of the nutmeg.
  6. Cook for approximately 50 minutes until the top is golden and potatoes are softened.

## Tomato and Pesto Bruschetta (serves 2)

- 2 medium sized ciabatta
  - 4 ripe tomatoes
  - Handful of fresh basil leaves
  - 50g of pine nuts
  - 50g of parmesan
  - 1 clove of garlic
  - Squeeze of lemon juice
  - 2  of olive oil
1. Remove the paddle from your Halo Health Fryer. Place the rack into the bowl at its low height so the food is furthest away from the halogen heater.
  2. Place the ciabatta on its side and carefully cut it in half lengthways as you would a sandwich. Place the tomatoes in a pan of boiling water to remove the skins and chop them into chunks.
  3. To make the pesto blend together the remaining ingredients in a food processor or mini chopper.
  4. Lightly oil the rack and place the ciabatta so the flat side is facing upwards.
  5. Coat the top of each ciabatta slice with the chopped tomato and pesto, and a drizzle of olive oil. Cook for 5-10 minutes until golden.

## Szechuan King Prawns

This recipe has a delicious marinade which, ideally, should be allowed to infuse the prawns for 2-3 hours before cooking. Why not prepare this recipe in advance to make the most of its oriental flavours.

- 1lb /450g Tiger king prawns, deveined, legs removed, shells removed (tails intact)
- 2  of groundnut oil

### *For the marinade*

- 2 spring onions, roughly chopped
- 2 x 1 inch pieces of root ginger, peeled and crushed
- 50g of mangetout
- 1 teaspoon of sesame oil
- 3 tablespoon of Sake (rice wine)
- 1 teaspoon of sugar
- 6 tablespoons of soy sauce
- 1 dried red chilli, seeded and crushed


1. Fit the paddle into your Halo Health Fryer.
2. Combine all of the marinade ingredients in a mixing bowl and add the king prawns. Stir until the prawns are well coated then cover the bowl with cling film. Leave to marinate in the fridge for 2-3 hours.
3. Add the prawns to your Halo Health Fryer removable bowl along with the remaining marinade and the groundnut oil and cook for 5 minutes. The prawns are cooked when they turn pink.
4. Serve immediately.

*Tip:* soak the prawns in a bowl of cold water with half a peeled onion before marinating. This will make them softer when cooked!

# recipes - fish and seafood dishes

---

## Breaded Haddock Goujons with Lemon Mayonnaise (Serves 4)

- 4 boned haddock fillets, skins removed
  - 200g white bread crumbs
  - 75g plain flour
  - Salt and freshly ground pepper
  - 2 eggs, beaten
  - 2  of sunflower oil
  - 300ml mayonnaise
  - 3 teaspoons of lemon juice
  - 2 teaspoons of finely grated lemon zest
  - 1 clove garlic, crushed
  - 2 tablespoon of fresh chopped parsley
- 
1. Fit the paddle into your Halo Health Fryer.
  2. Using a sharp knife, carefully slice the haddock fillets into 2cm wide strips.
  3. Place the bread crumbs, eggs and flour separately into individual dishes, season the flour and sprinkle the bread crumbs with the herbs.
  4. Place the haddock into the flour dish and toss until coated, shake of the excess and then dip into the beaten egg. Next add the fish to the bread crumbs and toss until completely coated.
  5. Next roll each piece of fish between the palm of your hand and a flat surface to smooth out the goujon.
  6. Add the goujons leaving a gap between each. Drizzle the goujons with the sunflower oil and cook for approximately 6-7 minutes or until golden.
  7. To make the lemon mayonnaise, mix the mayonnaise with the lemon juice, lemon zest, garlic and herbs and spoon into ramekins.
  8. Serve the goujons with the dip and a salad of your choice.

---

## **Baked Salmon with a Parmesan Crust (Serves 4)**

- 4 fresh water salmon fillets, boned
  - 2 slices of bread, 1 or 2 days old is the best
  - 2 cloves of garlic
  - 50g parmesan cheese
  - 1 tablespoon of fresh basil
  - 1 tablespoon of fresh parsley
  - Salt and freshly ground black pepper
1. Remove the paddle from your Halo Health Fryer and insert the rack at its low height so the food is furthest away from the halogen heater. Lightly oil the rack.
  2. Place the bread, garlic, parmesan cheese and herbs into a food processor or mini chopper and process into a fine bread crumb consistency.
  3. Place the salmon fillets onto the grill rack, skin side down, and lightly brush with olive oil. Cook the fillets for 5-7 minutes, depending on the thickness.
  4. Open the lid and cover the top of each salmon fillet with the bread crumb mixture and season to taste.
  5. Cook for another 5 minutes until the fish becomes flaky and the topping is golden.


### **Pan Roasted Chicken Wrapped in Parma Ham with Mediterranean Vegetables**

- 2 chicken breasts, skin removed
  - Zest of one lemon
  - 4 slices of Parma ham
  - 1 garlic clove, crushed
  - 1 courgette, sliced
  - 1 aubergine, sliced
  - ½ can of chopped tomatoes
  - ½ a red pepper, sliced
  - ½ a yellow pepper, sliced
  - 50g of mozzarella (optional)
  - Handful of torn basil leaves
1. Remove the paddle from your Halo Health Fryer and insert the rack at its low height so the food is furthest away from the halogen heater.
  2. Cut each chicken breast in half lengthways, and add some lemon zest to each breast. Wrap the breast in two slices of Parma ham and secure it by pressing it together well.
  3. Lightly oil the rack and place the chicken on it.
  4. Cook them for approximately 10 minutes, turning if you desire halfway through.
  5. When the time has elapsed carefully remove the rack using oven gloves as this will be very hot.
  6. Place the vegetables, garlic and tomatoes in the bowl and drizzle generously with olive oil. Cook for a 10 minutes.
  7. Add the chicken to the bowl with the vegetables and cook for a further 10 minutes.
  8. Two minutes before the end of cooking, dot the mozzarella cheese in and around the vegetables and chicken and let it melt before serving.
  9. Serve scattered with the torn basil leaves. Warm ciabatta bread makes an ideal accompaniment.



---

## Sweet Chilli Chicken Stir Fry with Egg Fried Rice (Serves 4)

- 1  of sesame oil
- 4 skinless and boneless chicken breasts, cut into very thin strips
- 100g oyster mushrooms, roughly sliced
- 5 spring onions, sliced in 2cm pieces diagonally
- ½ red pepper, sliced
- 1 chilli, seeds removed and thinly sliced
- 225g can of water chestnuts
- 100g cashew nuts
- 2 garlic cloves, chopped
- 4 tablespoons of sweet chilli sauce
- 50ml chicken stock
- 1cm piece of ginger

### *Rice*

- 200g long grain rice
- 4 x medium eggs
- Soy sauce
- ½ a lemon


1. Fit the paddle into your Halo Health Fryer.
2. Rinse the rice and boil it in a pan with a dash of olive oil (this prevents the rice from sticking together). Allow it to cook for 10 minutes or until tender. Once the rice is cooked, drain and immediately rinse it under cold water. Set the rice to one side.
3. Meanwhile, add the chicken and sesame oil to the fryer bowl and cook for 10 minutes or until golden. Then, add the garlic, chilli, ginger, sweet chilli sauce and chicken stock and cook for a further 5 minutes or until the sauce begins to thicken.
4. Next, add the mushrooms, onions, water chestnuts and cashew nuts and cook for 8 minutes.
5. Whilst cooking make the egg fried rice.
6. Heat some olive oil in a large frying pan on a high heat. Once hot, crack the eggs into the base of the pan. Add a generous splash of soy sauce to the egg.
7. Using a wooden spoon briskly swirl round the egg to break it up into pieces. Add the rice to the pan and stir.
8. Add another generous splash of olive oil and the juice of half a lemon. Stir until combined.
9. Serve the egg fried rice with the chicken stir fry.

## **Creamy Chicken Korma with fragrant rice (Serves 4)**

### *Rice*

- 300g Basmati rice
- 4 Cardamom pods, cracked
- 1 bay leaf

### *Curry*

- 1  of olive oil
- 4 chicken breasts, cubed
- 1 white onion, sliced
- 2 cloves of garlic, sliced
- 1cm piece of ginger, finely sliced
- 1 teaspoon of Garam Masala
- 200ml chicken stock
- 100ml coconut milk
- 2 heaped tablespoons of toasted sliced almonds
- 1 tablespoon of toasted sliced almonds to garnish

1. Fit the paddle into your Halo Health Fryer.
2. First, boil the rice in a pan along with the cardamom pods and bay leaf for 10 minutes or until the rice is tender.
3. Whilst the rice is cooking add the oil and chicken to your Halo Health Fryer and cook for 12 minutes or until the chicken is cooked through.
4. Next, add the onion, garlic, ginger and Garam Masala and cook for a further 3 minutes.
5. Add the stock, coconut milk and almonds the cook for a further 6 minutes so the flavours infuse.
6. Serve the Korma with the rice and sprinkle with the toasted almonds to garnish.

---

## Piri Piri Chicken Wings (Serves 4)

This recipe uses a fiery marinade, for less heat, reduce the amount of chillies. It is also ideal to prepare this dish 24 hours in advance. This allows the marinade to intensify on the chicken, producing a spicy Portuguese favourite!

- 800g chicken wings, slashed both sides


### *Marinade*

- 10 small red chillies
  - 1 ½ teaspoon dried oregano
  - 1 teaspoon paprika
  - 150ml red wine vinegar
  - 200 ml olive oil
  - 3 cloves of garlic, finely chopped
  - Juice of 1 lime
  - 2 tablespoon brown sugar
  - ¼ teaspoon salt
1. Using a food processor or mini chopper, combine all the marinade ingredients and blend until smooth.
  2. Place the chicken wings and the marinade together into a suitable resealable container and mix well to coat the chicken. Leave overnight if possible, stirring occasionally to keep the chicken coated.
  3. Remove the paddle from your Halo Health Fryer.
  4. Carefully remove the chicken from the marinade and place evenly into the bowl.
  5. Set the timer for 30 minutes, turning the chicken half way through cooking.
  6. Serve with toasted pitta bread, green salad and tomato salsa.

# recipes - beef and lamb dishes


---

## Braised Sausage in Red Wine (Serves 4)

- 1  olive oil
  - 1 tablespoon of flour
  - 6 Good quality pork sausages, cut into 1½ inch pieces
  - 100g bacon rashers, sliced into thin strips
  - 200g shallots, peeled
  - 300ml red wine
  - 1 x 400g can of chopped tomatoes
  - 160g button mushrooms
  - 1 bay leaf
  - 2 garlic cloves, crushed
  - 1 tablespoon of fresh thyme, stalks removed
  - Salt and freshly ground black pepper
- 
1. Remove the paddle from your Halo Health Fryer.
  2. Add the sausages, bacon and onions to the removable bowl and cook for 10-12 minutes until they are browned.
  3. Next add the flour and gradually stir in the wine.
  4. Add the remaining ingredients and cook for a further 20 minutes.

---

## Quick Beef Stroganoff with Fuselli Pasta

- 1  of olive oil
  - 1 lb of lean thin steak, cut into strips
  - 1 onion, halved then sliced
  - 1 clove of garlic, crushed
  - 100g button mushrooms
  - 1 red pepper, sliced
  - 100ml red wine
  - 2 teaspoons of Worcestershire Sauce
  - 150ml beef stock
  - 2 teaspoon of Dijon mustard
  - 2 teaspoon of freshly chopped parsley
  - 1 teaspoon of tomato puree
  - 30g plain flour
  - 110ml soured cream
  - 300g Fuselli pasta
1. Fit the paddle into your Halo Health Fryer
  2. Add the pasta to a pan of boiling water along with the olive oil and stir well. Leave to cook for approximately 8-10 minutes or until it is tender. Drain well.
  3. Whilst the pasta is cooking add the oil, steak, onions, garlic and pepper to the fryer bowl and cook for 6 minutes until the onions are softened and the steak begins to brown.
  4. Sprinkle the flour over the beef and gradually add the stock and wine.
  5. Add the remaining ingredients except the pasta, stir well and cook for a further 8-10 minutes. Serve with the pasta.

# recipes - beef and lamb dishes

---

## **Beef and Caramelized Red Onion Burgers (Makes 4)**

- 400g of good quality minced beef
- 1 small red onion, finely chopped
- 1 teaspoon of brown sugar
- 1 teapoon of dried mixed herbs
- 1 egg, beaten
- Handful of coriander leaves, chopped

*To serve* Bread rolls, cheese slices, sliced tomatoes, lettuce and ketchup

1. Remove the paddle from your Halo Health Fryer and insert the rack at its low height so the food is furthest away from the halogen heater.
2. In a frying pan gently sauté the chopped red onion on a low/medium heat with the olive oil and brown sugar for 5 minutes. Remove from the heat and set aside.
3. Work the mince together in a bowl with the caramelized onions and the beaten egg. You want to combine the mixture so that all the ingredients are mixed but don't make it too mushy and soft.
4. Stir in the chopped coriander and the dried herbs. Season to taste.
5. Take a handful of the mixture and form it into a burger shape. The mixture should make about 4 burgers. The thicker they are, the longer they will take to cook through.
6. Lay each burger on a board that has been covered in cling film and then cover them.
7. Put them in the fridge to chill for approximately 1 hour. This will help them to maintain their shape while cooking.
8. When you are ready to cook the burgers, place them on the grill rack.
9. Cook for 8 minutes on one side then turn them over with a spatula, being careful as your fryer will be hot. Cook them for a further 8-9 minutes until they are thoroughly cooked through
10. Serve the burgers on the bread rolls with cheese, tomato, lettuce and ketchup.

---

## Spicy Lamb Burgers (Serves 4)


- 400g of lean lamb mince
- ½ red onion, finely chopped
- 1 egg, beaten
- 1 tablespoon of mango chutney
- Handful of fresh coriander leaves, chopped
- ½ red chilli, deseeded and chopped
- 1 garlic clove, crushed
- ½ teaspoon of cumin
- ½ teaspoon of ground coriander

### *To serve*

- 4 x mini Ciabattas
- Mint, chopped
- Thick greek yogurt
- 1 cucumber, finely chopped

1. Remove the paddle from your Halo Health Fryer and insert the rack at its low height so the food is furthest away from the halogen heater.
2. In a bowl work together the lamb mince with the beaten egg.
3. Stir in the mango chutney, coriander leaves, chilli, garlic and the spices.
4. Work the mixture together with spoon and then pat the mixture into burger shapes.
5. Place them on a cling film lined tray and cover. Chill them in the fridge for approximately 1 hour.
6. Lightly oil the grill rack. Place four of the burgers onto the rack and brush the tops with olive oil.
7. Cook for approximately 9 minutes on one side. Carefully flip the burgers over with a spatula.
8. Cook for a further 8-9 minutes until they are thoroughly cooked through.
9. In bowl mix together the Greek yogurt, chopped cucumber and the mint.
10. Place the ciabatta under a grill for 1-2 minutes until it is toasted. Serve the lamb burgers on the ciabatta topped with the yogurt dressing.

## Basic Mushroom Risotto (Serves 2 as a main meal or 4 as a starter) (V)

- 2  of olive oil
- 1 onion, finely chopped
- 2 cloves of garlic
- 300g of risotto rice (Arborio)
- 1 litre of vegetable stock
- 150ml of dry white wine
- Salt and freshly ground pepper
- 150g of cooked mushrooms
- 40g of freshly grated parmesan
- 25g butter, diced


1. Fit the paddle into your Halo Health Fryer.
2. Pour in the olive oil and add the garlic and the onion and close the lid. Cook for approximately 5 minutes until the onions are golden.
3. Add the rice and cook for a further minute. Add the wine and 500ml of the stock stirring well. Season to taste.
4. Cook for approximately 30 minutes.
5. Halfway through cooking add the remaining 500ml of stock.
6. Continue cooking for approximately 30 to 35 minutes until the rice is tender.
7. When the rice is ready, stir in the parmesan cheese, cooked mushrooms and the butter. Set the timer to cook for another 2 minutes

*Variations:* Try adding additional ingredients halfway through cooking such as cooked bacon, asparagus spears, peas, smoked haddock or chicken.




---

## Roasted Asparagus with Parmesan (Serves 4) (V)

- 400g fresh Asparagus
  - 2  of olive oil
  - 1 teaspoon of freshly ground pepper
  - 1 teaspoon of sea salt
  - 1 tablespoon of balsamic vinegar
  - 30g of parmesan cheese, freshly grated
1. Fit the paddle into your Halo Health Fryer.
  2. Wash and trim the asparagus, so that the hard stalk end is removed.
  3. Place the asparagus into the bowl and pour over the olive oil and balsamic vinegar
  4. Sprinkle with freshly ground pepper and sea salt
  5. Cook for 10-15 minutes until the stalks are tender
  6. Serves with the parmesan cheese sprinkled over

## Goats Cheese Stuffed Mushrooms (Serves 4) (V)

- 4 large flat mushrooms
  - 1½  of olive oil
  - ½ red onion, finely chopped
  - 4 tablespoons of white bread crumbs
  - 2 cloves of garlic, crushed
  - 50g of goat's cheese, crumbled
  - Freshly ground black pepper
1. Remove the paddle to your Halo Health Fryer. Lightly oil the removable bowl.
  2. Mix together half of the oil with the onions, bread crumbs, garlic and crumbled goat's cheese with some freshly ground pepper in a bowl
  3. Place the mushrooms flat in the fryer bowl and spoon the goat's cheese mixture over the top.
  4. Drizzle a little of the remaining oil over the top and cook for 10-15 minutes.

## Crème Brulee (Makes 4)

- 250ml double cream
  - 1 vanilla pod, or 1 teaspoon of vanilla extract
  - 50g caster sugar
  - 3 free-range egg yolks
  - Brown sugar for the topping
  - Raspberries to decorate
1. Remove the paddle from your Halo Health Fryer.
  2. Pour the cream into a saucepan. If you are using a vanilla pod split it lengthways and scrape the seeds into the cream. Then chop the pod into small pieces and add to the cream. Alternatively, pour in the vanilla extract.
  3. Bring the cream to the boil and then turn the heat down so that it is simmering. If you have used a vanilla pod, strain the cream to remove it and then add the cream back to the pan.
  4. Meanwhile, whisk the egg yolks together in a bowl until they are frothy and then whisk in the sugar.
  5. Pour the cream into the eggs and sugar whisking constantly. This will slightly cook the eggs and the mixture will thicken somewhat.
  6. Add the mixture to four ramekins so that they are approximately two thirds full and then place them in the fryer bowl. Carefully pour enough water around the ramekins so that it reaches halfway up the sides.
  7. Cover the ramekins with a circle of foil and cook for 30-35 minutes until they are set.
  8. Once set, remove the foil and sprinkle the tops with brown sugar. Cook uncovered for a further 5 minutes until the top goes brown and caramelized.
  9. Serve with the raspberries.

---

## Nutty Baked Apples with Butterscotch Sauce (Serves 4)

- 500g apples, Cox's, Russet or Braeburn
- 50g hazelnuts, chopped
- 50g unsalted butter
- 1 vanilla pod, de-seeded

### *Butterscotch sauce*

- 30g butter
- 100g light muscovado sugar
- 2 tablespoons of golden syrup
- 142ml pot double cream

1. Remove the paddle, coat it with some butter then refit it.
2. Core and peel the apples then place them in the removable bowl. Dot the remaining butter around the apples.
3. Cook them for approximately 15 minutes. Remove the lid and sprinkle on the hazelnuts and the vanilla pod on the apples. Cook for a further 3 minutes until the hazelnuts are golden.
4. To make the butterscotch sauce, gently heat the butter, muscovado sugar, golden syrup and the cream in a saucepan, stirring occasionally until it is smooth.
5. Serve the baked apples with the sauce poured over.

## Warm Tropical Fruit Salad

- 100ml of orange juice
- 30g of golden caster sugar
- 1 teaspoon of vanilla extract
- 1 orange, zested
- 1 ripe mango, peeled and de-stoned
- 1 pineapple, prepared
- 2 ripe peaches or nectarines, de-stoned
- 2 passion fruits (pulp and seeds)

1. Remove the paddle from your Halo Health Fryer and insert the rack at its low height.
2. Have a bowl of iced water ready.
3. In a small pan on a low to medium temperature, heat the orange juice, sugar, vanilla, orange zest and passion fruit until the sugar has dissolved. Quickly place the pan into the cold water so that the mixture forms a syrup.
4. Cut the prepared fruit into slices. It is attractive to cut the pineapple into rings, the peaches or nectarines into segments and the mango into wedges but you can prepare the fruit any way you like.
5. Place the fruit in the fryer bowl and coat it with the syrup and peppercorns. Cook for approximately 5 minutes until softened and juicy.
6. Serve with thickly whipped cream or vanilla ice cream.

## Sponge recipe

This quick all-in-one sponge cake recipe is suitable for a 25cm sponge or it will make 6-8 individual cupcakes or buns.

- 100g softened butter or margarine
  - 100g castor sugar
  - 2 eggs
  - Few drops of vanilla essence
  - 100g Self raising flour
  - ½ teaspoon baking powder
1. Place the ingredients into a bowl and using a hand mixer whisk all the ingredients together until a light creamy mixture is achieved.
  2. Remove the paddle from your Halo Health Fryer and line the base of the bowl with baking parchment. Cut a hole in the centre of the parchment large enough to fit over the paddle drive spindle (approx. 40 mm).
  3. Using a spatula, spread the cake mixture over the base of the bowl ensuring the mixture reaches the sides. Even out the mixture to ensure the cake rises evenly during baking.
  4. Place the bowl inside your Halo Health Fryer and set the timer for 15 minutes. Press the on button.
  5. At the end of the cooking time, remove the bowl carefully using the handle attachment.
  6. Place the bowl onto a wire cooling rack for 5 minutes to cool. Turn the bowl over and the sponge will easily turn out. Peel off the baking parchment and leave to cool for a further 30 minutes.
  7. This single layer sponge can be topped with cream and berries, or repeat the above steps to make another sponge for a Victoria Sandwich cake.

## Fillings

Whipped cream, seedless raspberry jam, butter icing filling, fresh or frozen berries are all perfect ingredients which can be used for this light, golden sponge.

---

## Individual Cup cakes

1. Prepare the recipe above. Fill 6-8 silicone cupcake moulds  $\frac{1}{2}$  full with the cake mixture.
2. Remove the paddle from your Halo Health Fryer.
3. Place the filled moulds inside the removable bowl, close the lid and set the timer for 10 minutes.
4. Once cooked, carefully remove the bowl, placing it onto a cooling wire. After 5 minutes remove the cakes from the bowl and cool for a further 15 minutes before decorating.

## Halo Sponge Recipe Guidelines

This recipe will make a 25cm sponge perfect for cutting into shapes and decorating for mini cake bites and decorated cakes, or for the base of a homemade fruit trifle.

Alternatively, double the mixture and make two sponges, which can then be filled and decorated.

When making a large sponge cake, always line the bottom of the bowl of your Halo Health Fryer with baking parchment. This will ensure the cake turns out perfectly each time. Cut a small hole in the centre of the parchment so that the parchment fits over the paddle drive spindle.

Because of the paddle drive spindle, any cakes you make will naturally have a hole in their centre—but don't worry because this can be filled with berries or fruits during decorating.

**IMPORTANT:** Always remove the paddle before making a cake.

No pre-heating is required; your Halo Health Fryer will cook the sponge in 12 – 15 minutes.

Do not attempt to bake more than the quantities recommended in the recipe at any one time. This will result in the cake that's burnt on the surface and uncooked in the centre. This recipe has been tested and produces a light sponge, which is perfect for filling with whipped cream and raspberry jam.

Alternatively, fill some individual silicone moulds  $\frac{1}{2}$  full with the mixture and make some cup cakes. Your Halo Health Fryer bakes 6 large cup cake size buns in 10 minutes

# connection to the mains supply

---


**⚠ This appliance must be earthed.**

If the plug is not suitable for the socket outlets in your home, it can be removed and replaced by a plug of the correct type.

If the fuse in a moulded plug needs to be changed, the fuse cover must be refitted. The appliance must not be used without the fuse cover fitted.

If the plug is unsuitable, it should be dismantled and removed from the supply cord and an appropriate plug fitted as detailed. If you remove the plug it must not be connected to a 13 amp socket and the plug must be disposed of immediately.

If the terminals in the plug are not marked or if you are unsure about the installation of the plug please contact a qualified electrician.



Ensure that the outer sheath of the cable is firmly held by the cord grip

These appliances are built to the very highest of standards. There are no user serviceable parts. Follow these steps if the unit fails to operate:

1. Check the instructions have been followed correctly.
2. Check that the fuse has not blown.
3. Check that the mains supply is functional.

If the appliance will still not operate, return the appliance to the place it was purchased for a replacement. To return the appliance to the Customer Service Department, follow the steps below:

1. Pack it carefully (preferably in the original carton). Ensure the unit is clean.
2. Enclose your name and address and quote the model number on all correspondence.
3. Give the reason why you are returning it.
4. If within the guarantee period, state when and where it was purchased and include proof of purchase (e.g. till receipt).
5. Send it to our Customer Service Department at the address below:

**Customer Service Department**  
**Jarden Consumer Solutions (Europe) Limited**  
**Middleton Road, Royton, Oldham OL2 5LN, UK.**  
**Telephone: 0161 621 6900 Fax: 0161 626 0391**  
**e-mail: [enquiriesEurope@jardencs.com](mailto:enquiriesEurope@jardencs.com)**

## Replacement parts

For additional or replacement parts, please visit [www.breville.co.uk](http://www.breville.co.uk) or call us on **0161 621 6900**.

## Troubleshooting

For troubleshooting and FAQs visit [www.breville.co.uk/faqs](http://www.breville.co.uk/faqs)

## Turn on your Creativity™

Let the Breville® team help you turn on your creativity with a gateway to a world of food and drinks without limits. You don't have to travel far—just to your computer, tablet or mobile—where you will discover our FREE website with top tips and recipes to inspire your imagination. Join us now at [www.turnonyourcreativity.com](http://www.turnonyourcreativity.com)

Turn  your creativity™

# guarantee

---

Please keep your receipt as this will be required for any claims under this guarantee.

This appliance is guaranteed for 1 year after your purchase as described in this document.

During this guaranteed period, if in the unlikely event the appliance no longer functions due to a design or manufacturing fault, please take it back to the place of purchase, with your till receipt and a copy of this guarantee.

The rights and benefits under this guarantee are additional to your statutory rights, which are not affected by this guarantee. Only Jarden Consumer Solutions (Europe) Limited (“JCS (Europe)”) has the right to change these terms.

JCS (Europe) undertakes within the guarantee period to repair or replace the appliance, or any part of appliance found to be not working properly free of charge provided that:

- you promptly notify the place of purchase or JCS (Europe) of the problem; and
- the appliance has not been altered in any way or subjected to damage, misuse, abuse, repair or alteration by a person other than a person authorised by JCS (Europe).


Faults that occur through, improper use, damage, abuse, use with incorrect voltage, acts of nature, events beyond the control of JCS (Europe), repair or alteration by a person other than a person authorised by JCS (Europe) or failure to follow instructions for use are not covered by this guarantee. Additionally, normal wear and tear, including, but not limited to, minor discoloration and scratches are not covered by this guarantee.

The rights under this guarantee shall only apply to the original purchaser and shall not extend to commercial or communal use.

If your appliance includes a country-specific guarantee or warranty insert please refer to the terms and conditions of such guarantee or warranty in place of this guarantee or contact your local authorized dealer for more information.

Waste electrical products should not be disposed of with Household waste. Please recycle where facilities exist. E-mail us at [enquiriesEurope@jardencs.com](mailto:enquiriesEurope@jardencs.com) for further recycling and WEEE information.

Jarden Consumer Solutions (Europe) Limited  
5400 Lakeside  
Cheadle Royal Business Park  
Cheadle  
SK8 3GQ  
UK











# Breville®

Jarden Consumer Solutions (Europe) Limited  
Cheadle Royal Business Park, Cheadle, SK8 3GQ, United Kingdom  
e-mail: [enquiriesEurope@jardencs.com](mailto:enquiriesEurope@jardencs.com)  
Telephone: 0161 621 6900

For Customer Service details, please see the website.

[www.breville.co.uk](http://www.breville.co.uk)

**© 2015 Jarden Consumer Solutions (Europe) Limited**

All rights reserved. Imported and distributed by Jarden Consumer Solutions (Europe) Limited,  
Cheadle Royal Business Park, Cheadle, SK8 3GQ, United Kingdom.

The product supplied may differ slightly from the one illustrated due to continuing product development.

Printed in China